


CAUTION

Do NOT place your fingers inside the shell

Do NOT place your fingers inside the shell, as you may hurt yourself or cause damage to the PDX-100. Or when changing the head, do NOT touch any of the internal parts. Also, do not insert your fingers into the hole of the mounting bracket.



IMPORTANT NOTES

Placement

- Do not expose the unit to direct sunlight, place it near devices that radiate heat, leave it inside an enclosed vehicle, or otherwise subject it to temperature extremes. Excessive heat can deform or discolor the unit.
- When moved from one location to another where the temperature and/or humidity is very different, water droplets (condensation) may form inside the unit. Damage or malfunction may result if you attempt to use the unit in this condition. Therefore, before using the unit, you must allow it to stand for several hours, until the condensation has completely evaporated.
- Do not allow rubber, vinyl, or similar materials to remain on this unit for long periods of time. Such objects can discolor or otherwise harmfully affect the finish.
- Do not put anything that contains water on this unit. Also, avoid the use of insecticides, perfumes, alcohol, nail polish, spray cans, etc., near the unit. Swiftly wipe away any liquid that spills on the unit using a dry, soft cloth.

Maintenance

- For everyday cleaning wipe the unit with a soft, dry cloth or one that has been slightly dampened with water. To remove stubborn dirt, use a cloth impregnated with a mild, non-abrasive detergent. Afterwards, be sure to wipe the unit thoroughly with a soft, dry cloth.
- Never use benzine, thinners, alcohol or solvents of any kind, to avoid the possibility of discoloration and/or deformation.

Additional Precautions

- Use a reasonable amount of care when using the output jack. Rough handling can lead to malfunctions.
- When disconnecting all cables, grasp the connector itself—never pull on the cable. This way you will avoid causing shorts, or damage to the cable's internal elements.
- When you need to transport the unit, package it in the box (including padding) that it came in, if possible. Otherwise, you will need to use equivalent packaging materials.

Copyright © 2012 ROLAND CORPORATION

All rights reserved. No part of this publication may be reproduced in any form without the written permission of ROLAND CORPORATION.



Roland and V-Drums are either registered trademarks or trademarks of Roland Corporation in the United States and/or other countries.

Getting Started

Contents of the Package

- PDX-100 (pad unit)
- Connection cable
- Drum key
- Owner's manual (this manual)

Names of Components



Main Specifications

Roland PDX-100: V-Pad

Head Size	10 inches
Triggers	2 (Head, Rim)
Dimensions	310 (W) x 325 (D) x 90 (H) mm 12-1/4 (W) x 12-13/16 (D) x 3-9/16 (H) inches
Weight	1.8 kg 4 lbs
Accessories	Owner's Manual, Connection Cable, Drum Key
Options	Pad Mount (MDH series), Drum Stands (MDS series)

* In the interest of product improvement, the specifications and/or appearance of this unit are subject to change without prior notice.

Using the PDX-100

To play the PDX-100 efficiently

- BEFORE playing the pad, you must tension the head. See Page 5.
- Trigger type and trigger parameters in the sound module must be adjusted. See Page 6.

Adjusting the Head Tension

Before using the pad, tighten the head so that the tension is rather firm.


Looseness in the head tension may result in problems such as failure of the PDX-100's rim shots to sound or double triggering.

NOTE

Striking the head when the head tension is loose may damage the sensor.


1. Use the included drum key to tighten the tuning bolts.

Strike the head to check the feel and response.



Tighten each tuning bolt one by one, observing the numerical order shown in the diagram.

Do not firmly tighten a single tuning bolt by itself. Doing so will make it impossible to tension the head evenly, and will cause malfunctions.



2. Fine-tune the adjustment while continuing to check the pad feel and response.


MEMO

- On the PDX-100, adjusting the head tension affects only the head response, and does not change the pitch of the sound as it would on an acoustic drum.
- Head tension may slacken with the passage of time. Readjust the tension as needed.

Attaching the Pad to a Stand


The PDX-100 can be attached to a stand that has either a vertical rod or a horizontal pipe.

Stand with vertical rod (MDS series)



Acceptable rod diameters: 9.0-13.0 mm (3/8 to 9/16 inch)

Stand with horizontal pipe



Usable pipe size: 22.2 mm (7/8 inch)

Connecting to the Percussion Sound Module

Use the included stereo cables to connect pads to your percussion sound module (sold separately).

Connect the L-shaped end of the cable to the pad's OUTPUT jack.

Using a monaural cable will NOT allow rim shots or positional sensing.


MEMO

Refer to the table below for details on trigger inputs of sound modules supporting rim shots.

NOTE

Prevent malfunction and/or damage to speakers or other devices by always turning down the volume, and/ or power of all devices before making any connections.

Example: Percussion Sound Module TD-30



Trigger Parameter Settings on the Sound Module

Compatibility with various sound modules

Model	Head Shot	Rim Shot	Cross Stick	Positional Sensing	Rim Shot Nuance	Brush Sweep
TD-30 TD-20X/ TDW-20/ TD-20/ TD-12	✓	✓	✓	✓	✓	✓
TD-15/ TD-11/ TD-9/ TD-4	✓	✓	✓	—	—	—

MEMO

For details, refer to the owner's manual of your percussion sound module.

Recommended parameter settings

Below please find recommended trigger parameter settings when using the PDX-100 with various sound modules.

Further trigger parameter adjustment may be needed depending on the way in which the PDX-100 is mounted or the playing environment.

For details on editing refer to the owner's manual of your sound module.

Model	Parameter	Value
TD-30	Trig Type	PDX100
TD-15/ TD-11	Pad Type	PDX100
TD-20X/ TDW-20/ TD-12	Trig Type	PD105X
	Sensitivity	6
	Rim Gain	1.8
	Rim Shot Adjust	2.5
TD-20	Trig Type	PD105
	Sensitivity	6
	Rim Gain	1.8
	Rim Shot Adjust	2.5
TD-9/ TD-4	Trig Type	PD105
	Sensitivity	7
	Rim Gain	1.8
	Rim Shot Adjust (Rim Adjust)	2.5

	TD-30/ TD-20X/ TD-20/ TDW-20	TD-12	TD-15/ TD-11/ TD-9	TD-4
Inputs that allow rim shots	2 SNARE, 3-6 TOM 1-4, 12-15 AUX 1-4	2 SNARE, 3-5 TOM 1-3, 11-12 AUX 1-2	SNARE, TOM 1-3, AUX	SNARE
Inputs that allow cross-stick	2 SNARE	2 SNARE	SNARE	SNARE
Inputs that allow positional sensing	2 SNARE (TD-30 only) 3-6 TOM 1-4, 12-15 AUX 1-4	2 SNARE	—	—


Replacing the Head or Hoop Rubber

The performance of the head and/or hoop rubber will diminish with use over time. If the head is torn or becomes too fatigued, or impossible to tension correctly, then it should be replaced. If the hoop rubber is worn out, it too can be replaced.

For replacement heads or to have the hoop rubber replaced, please contact your dealer or a Roland service center.

Replacing the Head

1. Remove all tuning bolts from the PDX-100.



NOTE

Do not apply excessive force to the sensor and cushion located under the head. Doing so can interfere with accurate detection, and may damage it.

2. Remove the hoop.
3. Remove the old head, and place the new head on the frame.
4. Place the hoop onto the head.
5. Attach the tuning bolts to the hoop and frame.
6. Next, adjust the tension of the head. Refer to "Adjusting the Head Tension" (p. 5).


NOTE

Do not firmly tighten a single tuning bolt by itself. Doing so will make it impossible to tension the head evenly, and will cause malfunctions

Playing Methods

Head shots

Only playing the head and with certain snare sounds, the playing position will change the sound's nuance.




MEMO

Refer to the owner's manual of your percussion sound module for more info about which sounds allow this.

Rim shots

Strike the head and the rim of the pad simultaneously. You can play a different sounds (rim sounds) from when you strike the head.



Cross stick

Only strike the rim of the pad. Depending on the instrument assigned to the rim you can play rim shots and/or cross stick sounds.



Do not place your hand on the head

NOTE


To play the cross stick, be sure that you only strike the rim of the pad. Placing your hand on the head of the pad might prevent the cross stick sound from being played properly.

Change the Nuance of the Rim Shot

With certain snare and tom sounds, slight changes in the way you play rim shots changes the nuance.


Normal rim shots (open rim shots)

Strike the head and rim simultaneously.



Shallow rim shots

Simultaneously strike the head near the rim and the rim itself.



MEMO

- Refer to the owner's manual of your percussion sound module for more info about which sounds allow this.
- For more information on the trigger inputs of the various sound modules that support the use of nuance with rim shots, refer to p. 6.

WARNING

This product contains chemicals known to cause cancer, birth defects and other reproductive harm, including lead.

For China

有关产品中所含有害物质的说明

本资料就本公司产品中所含的特定有害物质及其安全性予以说明。

本资料适用于 2007 年 3 月 1 日以后本公司所制造的产品。

环保使用期限



此标志适用于在中国国内销售的电子信息产品，表示环保使用期限的年数。所谓环保使用期限是指在自制造日起的规定的期限内，产品中所含的有害物质不致引起环境污染，不会对人身、财产造成严重的不良影响。环保使用期限仅在遵照产品使用说明书，正确使用产品的条件下才有效。不当的使用，将会导致有害物质泄漏的危险。

产品中有毒有害物质或元素的名称及含量

部件名称	有毒有害物质或元素					
	铅(Pb)	汞(Hg)	镉(Cd)	六价铬(Cr(VI))	多溴联苯(PBB)	多溴二苯醚(PBDE)
外壳(壳体)	×	○	○	○	○	○
电子部件(印刷电路板等)	×	○	×	○	○	○
附件(电源线、交流适配器等)	×	○	○	○	○	○

○：表示该有毒有害物质在该部件所有均质材料中的含量均在 SJ/T11363-2006 标准规定的限量要求以下。
 ×：表示该有毒有害物质至少在该部件的某一均质材料中的含量超出 SJ/T11363-2006 标准规定的限量要求。
 因根据现有的技术水平，还没有什么物质能够代替它。

For EU Countries



UK This symbol indicates that in EU countries, this product must be collected separately from household waste, as defined in each region. Products bearing this symbol must not be discarded together with household waste.

DE Dieses Symbol bedeutet, dass dieses Produkt in EU-Ländern getrennt vom Hausmüll gesammelt werden muss gemäß den regionalen Bestimmungen. Mit diesem Symbol gekennzeichnete Produkte dürfen nicht zusammen mit dem Hausmüll entsorgt werden.

FR Ce symbole indique que dans les pays de l'Union européenne, ce produit doit être collecté séparément des ordures ménagères selon les directives en vigueur dans chacun de ces pays. Les produits portant ce symbole ne doivent pas être mis au rebut avec les ordures ménagères.

IT Questo simbolo indica che nei paesi della Comunità europea questo prodotto deve essere smaltito separatamente dai normali rifiuti domestici, secondo la legislazione in vigore in ciascun paese. I prodotti che riportano questo simbolo non devono essere smaltiti insieme ai rifiuti domestici. Ai sensi dell'art. 13 del D.Lgs. 25 luglio 2005 n. 151.

ES Este símbolo indica que en los países de la Unión Europea este producto debe recogerse aparte de los residuos domésticos, tal como está regulado en cada zona. Los productos con este símbolo no se deben depositar con los residuos domésticos.

PT Este símbolo indica que nos países da UE, a recolha deste produto deverá ser feita separadamente do lixo doméstico, de acordo com os regulamentos de cada região. Os produtos que apresentem este símbolo não deverão ser eliminados juntamente com o lixo doméstico.

NL Dit symbool geeft aan dat in landen van de EU dit product gescheiden van huishoudelijk afval moet worden aangeboden, zoals bepaald per gemeente of regio. Producten die van dit symbool zijn voorzien, mogen niet samen met huishoudelijk afval worden verwijderd.

DK Dette symbol angiver, at i EU-lande skal dette produkt opsamlles adskilt fra husholdningsaffald, som defineret i hver enkelt region. Produkter med dette symbol må ikke smides ud sammen med husholdningsaffald.

NO Dette symbolet indikerer at produktet må behandles som spesialavfall i EU-land, iht. til retningslinjer for den enkelte regionen, og ikke kastes sammen med vanlig husholdningsavfall. Produkter som er merket med dette symbolet, må ikke kastes sammen med vanlig husholdningsavfall.

SE Symbolen anger att i EU-länder måste den här produkten kasseras separat från hushållsavfall, i enlighet med varje regions bestämmelser. Produkter med den här symbolen får inte kasseras tillsammans med hushållsavfall.

FI Tämä merkintä ilmaisee, että tuote on EU-maissa kerättävä erillään kotitalousjätteistä kunkin alueen voimassa olevien määräysten mukaisesti. Tällä merkinnällä varustettuja tuotteita ei saa hävittää kotitalousjätteiden mukana.

HU Ez a szimbólum azt jelenti, hogy az Európai Unióban ezt a terméket a háztartási hulladéktól elkülönítve, az adott régióban érvényes szabályozás szerint kell gyűjteni. Az ezzel a szimbólummal ellátott termékeket nem szabad a háztartási hulladék közé dobni.

PL Symbol oznacza, że zgodnie z regulacjami w odpowiednim regionie, w krajach UE produktu nie należy wyrzucać z odpadami domowymi. Produktów opatrzonych tym symbolem nie można utylizować razem z odpadami domowymi.

CZ Tento symbol udává, že v zemích EU musí být tento výrobek sbírán odděleně od domácího odpadu, jak je určeno pro každý region. Výrobky nesoucí tento symbol se nesmí vyhazovat spolu s domácím odpadem.

SK Tento symbol vyjadruje, že v krajinách EÚ sa musí zber tohto produktu vykonávať oddelene od domového odpadu, podľa nariadení platných v konkrétnej krajine. Produkty s týmto symbolom sa nesmú vyhazovať spolu s domovým odpadom.

EE See sümbol näitab, et EL-i maades tuleb see toode olemprügist eraldi koguda, nii nagu on igas piirkonnas määratletud. Selle sümboliga märgitud tooteid ei tohi ära visata koos olemprügiga.

LT Šis simbolis rodo, kad ES šalyse šis produktas turi būti surenkamas atskirai nuo buitinių atliekų, kaip nustatyta kiekviename regione. Šiuo simboliu paženklinoti produktai neturi būti išmetami kartu su buitinių atliekomis.

LV Šis simbols norāda, ka ES valstīs šo produktu jāievāc atsevišķi no mājsaimniecības atkritumiem, kā noteikts katrā reģionā. Produkta ar šo simbolu nedrīkst izmest kopā ar mājsaimniecības atkritumiem.

SI Ta simbol označuje, da je treba proizvod v državah EU zbirati ločeno od gospodinskih odpadkov, tako kot je določeno v vsaki regiji. Proizvoda s tem znakom ni dovoljeno odlagati skupaj z gospodinskimi odpadki.

GR Το σύμβολο αυτό υποδηλώνει ότι στις χώρες της Ε.Ε. το συγκεκριμένο προϊόν πρέπει να συλλέγεται χωριστά από τα υλικά οικιακά απορρίμματα, σύμφωνα με όσα προβλέπονται σε κάθε περιοχή. Τα προϊόντα που φέρουν το συγκεκριμένο σύμβολο δεν πρέπει να απορρίπτονται μαζί με τα οικιακά απορρίμματα.