

Nombre de Page Puces Epson

| | | | | |
|----------------------------|--|--|--------|---------------|
| C13S050709 | Epson M200 | Epson AcuLaser M200/MX200 | BK | 2.5K |
| S050650 | Epson M1400 | Epson AcuLaser M1400/MX14/MX14NF | BK | 2.2K |
| S051170 | Epson M4000 | Epson AcuLaser M4000 | BK | 20K |
| S050583/82 | Epson M2300 | Epson AcuLaser M2300/2400/MX20 | BK | 3K,8K |
| S050587 | Epson M2310 | Epson AcuLaser M2310/2410 | BK | 3K,9K |
| S050435 | Epson M2000 | Epson M2000/2010 | BK | 8K |
| M1200 OEM | Epson M1200 OEM | Epson M1200 OEM | BK | 1.8K, 3.6K |
| S050167 | Epson EPL-6200L 3K | Epson EPL-6200/6200L | BK | 3K |
| S050166 | Epson EPL-6200 6K | Epson EPL-6200 | BK | 6K |
| S051090 | Epson EPL-N2020 | Epson EPL-N2020/N2500 | BK | 6K |
| S051091 | Epson EPL-N2500 | Epson EPL-N2500/N3000 | BK | 10K |
| S051111/S051112 | Epson EPL-N3000 | Epson EPL-N3000 | BK | 17K |
| N4000+ | Epson EPL-N4000+ | Epson EPL-N4000+ | BK | 23K |
| S051082 | Epson C7000/C8000 | Epson C7000/C8000/8200/C8500/8600 | Drum | 30K |
| LP8100 | Epson C8700/8100 | Epson C8700/8100 | Drum | 10K |
| SO50190 | Epson C1100/CX11 Toner-BK | Epson C1100/CX11 Toner, color universal | BK | 4K |
| SO50189 | Epson C1100/CX11 Toner-C | | C | 4K |
| SO50188 | Epson C1100/CX11 Toner-M | | M | 4K |
| SO50187 | Epson C1100/CX11 Toner-Y | | Y | 4K |
| C1100D | Epson C1100/CX11 Drum | Epson C1100/CX11 Drum | Drum | 14K |
| SO50149,46,47,48 | Epson AcuLaser 4100 Toner-K/C/M/Y | Epson AcuLaser 4100 Toner | KCMY | 8K |
| C4200 | Epson AcuLaser C4200 KCMY | Epson AcuLaser C4200 | KCMY | K10/CMY8 |
| C13S050557,56,55,54 | Epson AcuLaser C1600/CX16 KCMY universal | Epson AcuLaser C1600/CX16 KCMY color&version universal | KCMY | 2.7K |
| C13S050614,13,12,11 | Epson AcuLaser C1700 KCMY | Epson AcuLaser C1700/C1750W/CX17NF KCMY | KCMY | K:2/CMY:1.4 |
| C13S050229,28,27,26 | Epson AcuLaser C2600 KCMY | Epson AcuLaser C2600 | KCMY | 5K,7K |
| C13S051161,60,59,58 | Epson AcuLaser C2800 KCMY | Epson AcuLaser C2800 | KCMY | K:8/CMY:6 |
| C13S050213,12,11,10 | Epson AcuLaser C3000 KCMY | Epson AcuLaser C3000 | KCMY | K:4.5/CMY:3.5 |
| C13S051127,26,25,24 | Epson AcuLaser C3800 KCMY | Epson AcuLaser C3800 | KCMY | K:9.5/CMY:9 |
| C13S050593,92,91,90 | Epson AcuLaser C3900 Toner KCMY | Epson AcuLaser C3900N/C3900DN/CX37 Toner | T-KCMY | K:12/CMY:6 |
| C13S051204,03,02,01 | Epson AcuLaser C3900 Drum KCMY | Epson AcuLaser C3900N/C3900DN/CX37 Drum | D-KCMY | 30K |
| C13S050319,18,17,16 | Epson AcuLaser CX21N KCMY | Epson AcuLaser CX21N | KCMY | K:4.5/CMY:5K |
| C13S050630,29,28,27 | Epson AcuLaser C2900 KCMY | Epson AcuLaser C2900N/C2900DN/CX29n Toner | KCMY | K:3/CMY:2.5 |